GB

PROGRAMME CHART

A. "Door open" indication

This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately, e.g.:

B. "Service" indication
C. "Water tap closed" indication
D. "Clean pump" indication



E. Programme selector
F. "Start" button
G. Spin speed selector
H. Programme sequence indicator
I. "Reset" button
J. "Start delay" button
K. Time display

Programme		Care Labels	Max. Load kg	Type of wash / Notes *- Respect the manufacturer's recommendations on the care label*	Detergents and Additives			Special options							Max Spin Speed rpm
					Pre-wash I	Main Wash II	Softener	Start delay *Start-vorwahl*	Eco+ *Öko+*	Pre-wash *Vor-wäsche*	Easy ironing *Liecht-bügeln*	Intensive rinse *Intensiv-spülen*	Rinse hold *Spül-stopp*	Variable spin *Schleu-dern*	
Cotton / Hygienic+ *40 - 60 - 95 °C*	**Koch-/Buntwäsche Hygiene+** *40 - 60 - 95 °C*	95 60 40	5.0	Normally to heavily soiled bed linen, table linen and underwear, towels, shirts etc. made of cotton and linen. *Selecting "Cotton 95°, this programme eliminates bacteria, ensuring sanitization of your laundry. The bacterial removal efficiency has been tested following a similar methodology to the NF EN 13697 standard of Nov. 2001.* *With heavily soiled laundry the additional "Prewash" option can be additionaly selected.*	❊	Yes	❊	❊	❊	❊	❊	❊	❊	❊	Max.
Synthetics *40 - 60 °C*	**Pflegeleicht** *40 - 60 °C*	60 50 40	2.5	Normally soiled blouses, shirts, overalls etc. made of polyester (Diolen, Trevira), polyamide (Perlon, Nylon) or blends with cotton. *With heavily soiled laundry the additional "Prewash" option can be additionally selected.*	❊	Yes	❊	❊	❊	❊	❊	❊	❊	❊	1000 [1]
Sport *30 °C*	**Sport** *30 °C*	40 30 40 30	2.5	Normally soiled and/or sweaty sportwear made of cotton jersey or microfibres. *As this programme includes a prewash cycle, add detergent also to the prewash chamber. Do not add any softener*	Yes	Yes	–	❊	–	–	❊	❊	❊	❊	1000 [1]
Delicates *30 - 40 °C*	**Feinwäsche** *30 - 40 °C*	40 30	1.5	Curtains and delicate clothing, dresses, skirts, shirts and blouses. *With heavily soiled laundry the additional "Prewash" option can be additionally selected.*	❊	Yes	❊	❊	–	❊	–	–	❊	❊	1000 [1]
Daily load *40 °C*	**Mischwäsche** *40 °C*	60 40 60 40	3.0	Slightly to normally soiled textiles made of cotton and/or synthetics.	–	Yes	❊	❊	–	–	❊	❊	❊	❊	Max.
Quick wash *30 °C*	**Schnelle Wäsche** **30min.** *30 °C*	30	3.0	Shortly worn outer clothing made of cotton, polyester, polyamide and blends with cotton.	–	Yes	❊	❊	–	–	–	–	❊	❊	Max.
Wool *Cold - 40 °C*	**Wolle** *Kalt - 40 °C*	WOOLMARK	1.0	Only woollens labelled with the woolmark and identified as machine washable.	–	Yes	❊	❊	–	–	–	–	❊	❊	1000 [1]
Handwash *30 - 40 °C*	**Handwäsche** *30 - 40 °C*		1.0	Textiles made of linen, silk, wool and viscose marked as "handwashable".	–	Yes	❊	❊	–	–	–	–	❊	❊	400 [1]
Rinse & Spin	*Spülen & Schleudern*	–	5.0	*Same as the last rinse and the final spin in the "Cotton" programme.*	–	–	❊	❊	–	–	–	❊	❊	❊	Max.
Spin	*Schleudern*	–	5.0	*In this programme spinning is intensive. Same as the spin cycle in the "Cotton" programme.*	–	–	–	❊	–	–	–	–	–	❊	Max.
Gentle Spin	*Schonschleudern*	–	1.0	*In this programme spinning is gentle. Same as the spin cycle in the "Wool" programme.*	–	–	–	❊	–	–	–	–	–	❊	1000 [1]
Drain	*Abpumpen*	–	–	*Drain only - no spinning. Alternative method of terminating programme after "Rinse hold".*	–	–	–	❊	–	–	–	–	–	–	–

❊ : option / Yes : dosing required
[1] For improved garment care spin speed is restricted in these programmes

Bauknecht is a registered trademark of Whirlpool USA.

5019 401 01025

CONSUMPTION DATA

Programme	Temperature (°C)	Load (kg)	Water (l)	Energy (kWh)	Approx. Programme Duration (hours : minutes)*
Cotton / Hygienic+	95	5.0	49**	1.90	2:00
Cotton	60	5.0	44	0.95	2:10
Cotton with "Eco+"***	60	5.0	44	0.85	2:20
Cotton	40	5.0	44	0.60	2:00
Synthetics	60	2.5	50**	0.70	1:30
Synthetics	40	2.5	45	0.55	1:15
Sport	30	2.5	55	0.65	1:29
Delicates	30	1.5	50	0.50	0:45
Daily load	40	3.0	45	0.45	1:00
Quick wash	30	3.0	40	0.40	0:30
Wool	40	1.0	55	0.60	0:45
Handwash	40	1.0	45	0.60	0:40
Handwash	30	1.0	45	0.50	0:36

Consumption values were measured in normalized conditions in compliance with standard IEC/EN 60 456. Consumption data in the home may vary with respect to the values in the table in relation to the water supply pressure and temperature, the load and the type of wash.

* The remaining time indicator can deviate from the values in the table, because it takes into account the household conditions applicable at that time.

** To reduce the water temperature, some cold water is added at the end of the main wash cycle, before the pump drains the water out.

*** Reference Programme for Energy Label.

ADD DETERGENTS, CLOSE THE DOOR AND SELECT THE PROGRAMME

Add detergents as indicated on the front page and as described in the chapter "Detergent and Additives" in your Instructions for Use.

1. Turn the **programme selector** to the desired programme and temperature.
2. The **time display** shows the duration of the chosen programme (in hours and minutes), and the "**Start**" indication lamp blinks.
3. The indication lamp of the predefined spin speed lights up.

SELECT ANY DESIRED OPTION

Push the button(s) of any option(s) desired - the respective indication lamp lights up.
When the combination of programme and additional option(s) is not possible, the indication lights switch off automatically. Unsuitable combinations of options are deselected automatically.

"Eco+" button

- With modified temperature profile and a slightly prologned washing duration, the optimum combination of excellent washing result and even lower energy consumption is achieved.

"Prewash" button

- Only for heavily soiled loads (for example sand, granular dirt) sensible. Increases the cycle time by approximately 15 min.
- Do not use liquid detergent for the main wash when activating the "Prewash" option.

"Easy ironing" button

- Can be used together with "Cotton", "Synthetics" and "Daily load" programmes to make ironing easier.
- Increases the water quantity and the clothes are spun very gently.

"Intensive rinse" button

- More water is added and rinse cycle is prolonged.
- This option is particularly suitable for areas with very soft water, washing baby linen and helps people with allergies.

"Rinse hold" button

- The laundry remains in the last rinse water without pregressing to the final spin cycle to avoid creasing and prevent colours from changing.
- This option is particularly recommended for the programmes "Synthetics", "Daily load" and "Delicates".
- It is particularly useful if you want to postpone spinning to a later time, or if you want to drain only.
- If you select "Rinse hold" do not leave items to soak for too long.
  Note: The programme stops to "Rinse hold" at the time the "Rinse hold" lights in the preogramme sequence indication is on. The indication lamp next to the "Start" button blinks.

Terminate the "Rinse hold" option:

- Press the **"Start"** button; the programme will terminate automatically with the final spin cycle for the present wash programme.
- If you do not wish to spin the clothes, turn the programme selector knob to the "Drain" programme and press the **"Start"** button.

"Variable spin" button

- Every programme has a predefined spin speed.
- Press the button to set another spin speed.
- If spin speed "0" is selected, the final spinning is cancelled but intermediate spin peaks remain during rinse. The water is drained out only.

START DELAY

The "Start delay" allows to run the machine at the consumer's convenience, for example at night when electricity is cheaper. Do not use liquid detergent when activating "Start delay" option.

- Select programme, temperature and options.
- Press the "Start delay" button to select the delay time by 1 to 23 hours.
- Press the **"Start"** button.
  The countdown of the delay time begins; the "Start delay" indication lamp and the dot on the display will keep blinking until the programme starts.
- The time delay indication disappears when the programme starts and it is replaced by the remaining programme time.
- Once having pressed the **"Start"** button, the number of hours preselected can be reduced by pressing again the "Start delay" button.

To cancel the "Start delay"
...before you press the "Start" button:

- Turn the programme selector to another position or press the **"Reset"** button.

...after having pressed the "Start" button:

- Press the "Reset" button for at least 3 seconds - the start delay time disappears from the time display.

PROGRAMME START

Open the tap and press the **"Start"** button. The indication lamp next to the **"Start"** button lights up.
The programme sequence indicator shows the current programme phase, running from left to right through Wash, Rinse, Spin/Drain.
The time display shows the remaining programme time. Due to variations in load and temperature of inlet water, the remaining time is newly calculated in certain programme phases. If this is the case, an animation appears on the time display.

"DOOR OPEN" INDICATION

Before starting and after end of a programme, the lamp lights to show the the door can be opened. As long as a wash programme is running, the door remains locked and must on no account be forced open.
In case you have an urgent need to open it during a running programme, refer to "Cancel (Reset) a running programme before the end".

RED INDICATIONS

"Service"

Lighting up of the "Service" indication can be caused by a fault in an electrical component. Refer to the "Troubleshooting Guide" in your "Instructions for Use"; if the fault persists, contact our After Sales Service.

"Water tap closed"

The appliance has no or insufficient water supply. Open the water tap: if the indications still lights up, refer to the "Troubleshooting Guide" in the Instructions for Use.

"Clean pump"

Waste water is not pumped out. Check whether the drain hose is kinked or the filter must be cleaned: in the latter case refer to the Instructions for Use ("Removing the Filter").

PROGRAMME END

- All the lights of the programme sequence indicator are off, and the "Door open" indication lights up.

1. Turn the programme selector to the "Off/O" position.
2. Close the water tap.
3. Open the door and unload the machine.
4. Leave the door ajar to allow the drum to dry.

CHANGE PROGRAMME AND/OR OPTIONS AFTER PROGRAMME START

1. Press the **"Start"** button to pause the programme. The lamp blinks.
2. Select the new programme (with temperature), any options and another spin speed if you want.
3. Press the **"Start"** button again. The new programme continues at the same position where the previous programme was interrupted. Do not add detergent for this programme.

CANCEL (RESET) A RUNNING PROGRAMME BEFORE THE END

The **"Reset"** button cancels a programme before the end.

- Press the **"Reset"** button for at least 3 seconds; "rES" appears on the display. Any existing water is drained out before the door can be opened.

Bauknecht is a registered trademark of Whirlpool USA.

5019 401 01025